



Love Local Program - Kiosk TV Instructions

Here are simplified steps for using the 4K media box with the Kiosk TV:

1. **Turn on the TV:** Use the remote or the power button on the TV.
2. **Connect the 4K media box:** Make sure the Media Box is plugged in with both the HDMI cable and the power cable. The HDMI cable should also be connected to the TV.
3. **Select the correct input:** Go to the back of the TV and find which HDMI port the media box is connected to. Then, using the TV remote, press the input or source button and select the HDMI port.
4. **Load your media:** Plug a USB drive with an MP4 video or slide deck into the media box.
5. **Play the video:** Use the separate media box remote to navigate to the media section and press play on your video.
6. **Adjust settings if needed:** The media box remote also has extra settings

Graphic Specifications for TV:

- 1) It is recommended the video uploaded to the USB has a resolution of 1080 or above. Size of video should also be 1920 x 1080
- 2) Files are recommended to be MP4